



Vivid Collection

DJI Mavic Air 2S

What's Included

VIVID COLLECTION

Filters (ND8-PL | ND16-PL | ND32-PL) | Magnetic Case | Microfiber Cloth

Installation

Step 1

Install the filter before powering-on the drone.

Step 2

Support the gimbal in one hand. Using your other hand, push, and turn the stock UV counterclockwise and remove.

Step 3

Make sure your Air 2S lens is clean and clear of debris before filter installation.

Step 4

Support the gimbal in one hand. Using your other hand, place the filter tabs into their corresponding lens slots. When seated flush to the lens, turn clockwise until filter clicks into place.

Installation (Continued)

Step 5

Once installed, make sure the reference line aligns with the triangle on the filter base for horizontal polarization.

Pro Tip

For most natural looking composition, make sure the reference line aligns with the triangle on the filter base. Too much polarization can make your scene look unrealistic.

More Info

Tutorials

For additional help be sure to visit our YouTube page:

[youtube.com/polarprofilters](https://www.youtube.com/polarprofilters)

for tutorials and more.

Questions

Contact us at anytime via our website, or shoot us an email. We're happy to help.

polarpro.com | 949.220.9395

support@polarpro.com